


| NO. | PART NAME | PART NO. |
|------------------------|------------------------------------|----------|
| 1 | ROLLER HOUSING | 3682-00 |
| | ROLLER | 3683-00 |
| 2 | GLAZING - VINYL | W2286-CM |
| | GLAZING - ALUM. | W9353-06 |
| 3 | LATCH (HORIZONTAL ONLY) | 3781-00 |
| | LATCH SCREW | 3433 |
| 4 | SCREEN SPRING | 3768-00 |
| 5 | SCREEN CORNER | 2900 |
| 6 | SCREEN FRAME | W9349 |
| 7 | SASH GUIDE | 3685-00 |
| 8 | LATCH LIFT HANDLE - RH (VS) | 3018-00 |
| | LATCH LIFT HANDLE - LH (VS) | 3019-00 |
| 9 | BULB VINYL | 2029-05 |
| ITEMS NOT SHOWN | | |
| | PILE WEATHERSTRIP - SASH JAMBS | W7071-CM |
| | PILE WEATHERSTRIP - SASH INTERLOCK | 7081-00 |
| | SCREEN SPLINE | W2100-00 |
| | SCREEN CLOTH | W4200 |



**SERIES #23 VERTICAL/HORIZONTAL SLIDER
REPLACEMENT PARTS
(REPLACES SERIES 21)**