



# Old Style w/ Spiral Balance



NO.	PART NAME	PART NO.	MODEL USED ON
1	ROLLER ASS'Y.	4075	830, 830-DE
2	BALANCE COVER	W1223	810-T, 820-T
3	GLAZING BEAD	W1210	810-T, 820-T, 830, 830-DE
4	CAM LOCK	2590	810-T, 820-T, 830, 830-DE
5	CAM LOCK KEEPER	2577	810-T, 820-T, 830, 830-DE
6	SCREEN FRAME	W9358	810-T, 820-T, 830, 830-DE
7	SCREEN PULL TAB	3123 / 3799	810-T, 820-T, 830, 830-DE
8	TILT LATCH ASS'Y.	3546 LH / RH	810-T, 820-T
9	SCREEN SPRING	3768	810-T, 820-T, 830, 830-DE
10	SCREEN CORNER	3265	810-T, 820-T, 830, 830-DE
11	SPIRAL BALANCE	W3435	810-T, 820-T
12	BALANCE SHOE	3728	810-T, 820-T
13	PIVOT PIN	3610	810-T, 820-T
14	SCREEN SPLINE	W2100	810-T, 820-T, 830, 830-DE



MODELS 810-T / 820-T / 830 / 830-DE  
 VINYL VERTICAL AND HORIZONTAL SLIDERS  
 REPLACEMENT PARTS